

ELECTRICAL - BODY AND CHASSIS

ELECTRICAL CIRCUIT IDENTIFICATION (Cont'd.)

Circuit Number	Circuit Color	Circuit Name	Circuit Number	Circuit Color	Circuit Name
127	Dark Green	Two-Speed Axle - Switch on Shift Lever to Motor on Rear Axle (High) (Truck)	181	Light Blue	Power Seat - Solenoid - Fore and Aft
130	Color depends on Resonator Brown-White Black-Pink	Generator (Alternator) External Resistance 2 ohms per foot 1 ohm per foot	182	Yellow	Power Seat - 6-W - Aft and Down
131	Brown	Low Vacuum to Air Pressure Warning Light to Switch (Truck)	183	Light Blue	Tailgate - Window - Up
139	Pink-Black	Feed, Ign. Sw. "On" Controlled - Fused	184	Tan-White	Tailgate - Window - Down
140	Orange	Feed, Battery - Fused	189	Dark Green	Power Seat - 4-W - Fore and Down
141	Brown-White	Feed Ign. Sw. Accsy. Controlled Fused	190	Yellow	Power Seat - 4-W - Aft and Up
150	Black	Ground Circuit - Direct	191	Light Green	Power Seat - 4-W - Solenoid - Up and Down
151	Black	Ground Circuit - Direct	192	Purple	Defogger - High or Single Speed
152	Black	Ground Circuit - Direct	193	White-Purple & Orange	Defogger - Low Speed - .38 ohm/ft.
153	Black	Ground Circuit - Direct	198	Light Green	In-Car Sensor to Control
154	Black	Ground Circuit - Direct	199	Brown	Rear Seat Speaker - Feed from Radio Left Stereo
155	Black	Ground Circuit - Direct	200	Light Green	Front Speaker - Feed from Radio - Single or Right Stereo
156	White		201	Tan	Front Speaker - Feed from Radio - Left Stereo
157	White Black	Ground Circuit - Sw. Controlled - Body Interior Lamps - such as Dome, Courtesy, Map, Warning, etc.	202	Black	Compressor Overheat Switch to Thermal Limiter
158	White-Dark Green		203	Red/White	Rear Air Conditioning Potentiometer Feed
159	Black-Purple	Ground - Key Warning Buzzer	204	Brown	Ambient Temperature Switch to Thermal Limiter (Feed)
162	Gray	Power Top-Up	205	White/Black	Seat Belt Seat Sensor to Belt Retractor (Grd.)
163	Purple	Power Top-Down	206	Black	Neutral Start Switch to Buzzer and Lamp
164	Dark Blue	Window Control-L.F. - Up	207	Yellow/Black	Seat Sensor to Neutral Start Switch
165	Brown	Window Control-L.F. - Down	208	Black	Switch Controlled Ground (TCS)
166	Dark Blue	Window Control-R.F. - Up	209	Purple	Parking Brake Warning Lamp
167	Tan	Window Control-R.F. - Down	239	Pink-Black	Feed, Ign. Sw. "On" Controlled - Fused
168	Dark Green	Window Control-L.R. - Up	240	Orange	Feed, Battery - Fused
169	Purple	Window Control - L.R. - Down	241	Brown-White	Feed Ign. Sw. Accsy. Controlled - Fused
170	Light Green	Window Control - R.R. - Up	252	Gray	Electric Door Lock (Unlock)
171	Purple-White	Window Control - R.R. - Down	253	Light Green	Electric Door Lock (Lock)
178	Dark Green	Power Seat - 6-W - Fore and Aft	340	Orange	Feed, Battery - Fused
179	Tan	Power Seat - 6-W - Solenoid - Rear - Up and Down			
180	Light Green	Power Seat - 6-W - Solenoid - Frt. - Up and Down			

NOTE: Ground circuit numbers used in the order as listed, depending on the number of circuits at any one time.
 * When No. 35 circuit does not apply (normally on Vehicles with both Telltale Light and Standard Temperature Gauge.)